

TL	TASTO LINEA	POWER PUSH-BUTTON
CCB	CONTATTI CONTATTORE BOILER	BOILER CONTACTOR'S CONTACTS
CCLTM	CONTATTI CONTATTORE LTM	THERMIC DEVICE CONTACTOR'S CONTACTS
RB	RESISTENZA BOILER	BOILER HEATING ELEMENT
F	FILTRO ANTIDISTURBO RADIO	RADIO NOISE FILTER
BCLTM	BOBINA CONTATTI LTM	THERMIC DEVICE CONTACTOR'S COIL
LTM	LIMITATORE TERMICO	THERMIC DEVICE
PS	PRESSOSTATO	PRESSOSTAT
TB	TERMOSTATO BOILER	BOILER THERMOSTAT
BCB	BOBINA CONTATTORE BILER	BOILER CONTACTOR'S COIL
TV	TERMOSTATO VASCA	TANK THERMOSTAT
RV	RESISTENZA VASCA	TANK HEATING ELEMENT
LP	SPIA MACCHINA PRONTA	PILOT LIGHT MACHINE READY
BCV	BOBINA CONTATTORE VASCA	TANK CONTACTOR'S COIL
BCMPL	BOBINA CONTATTORE MPL	MPL CONTACTOR'S COIL
TPS	TASTO POMPA SCARICO	PUSH-BUTTON DRAIN PUMP
MPS	MOTOPOMPA SCARICO	MOTOR DRAIN PUMP
TC1	TEMPO CICLO 1	TIME CYCLE 1
TC2	TEMPO CICLO 2	TIME CYCLE 2
MPD	MOTORINO POMPA DETERGENTE	MOTOR DETERGENT PUMP
MP	MICROINTERRUTTORE PORTA	DOOR MICRO SWITCH
ELB	ELETTROVALVOLA BOILER	BOILER SOLENOID VALVE
MPL	MOTOPOMPA LAVAGGIO	WASH MOTOR PUMP
LC1	SPIA TEMPI CICLO	PILOT LIGHT CYCLE
LC2	SPIA TEMPI CICLO	PILOT LIGHT CYCE
LL	SPIA LINEA	PILOT LIGHT LINE
BR	BOBINA RELE	RELAY'S COIL
CR	CONTATTI RELE	RELAY'S CONTACT
CCV	CONTATTI CONTATTORE VASCA	TANK CONTACTOR'S CONTACTS
CCMPL	CONTATTI CONTATTORE MPL	MPL CONTACTOR'S CONTACTS
PT	PROTETTORE TERMICO	THERMAL PROTECTOR

THERMOSTOP NON COLLEGATO THERMOSTOP DISCONNECTED

SCHEMA ELETTRICO ECO 1000-ECO 1000 DP

THE ELECTRICAL DIAGRAM IS REPRESENTED BY FULLY OPTIONALS EQIPPED.

Lo schema rappresenta la macchina nella sua versione piu complessa sui modelli derivati piú semplici mancheranno alcuni componenti con le relative connessioni.